09727937 "050101



FIG. 1

T0T050" 2E627260



Fig. 2

FIG 3



FRAMER CHIP MODE CONTROL TABLE

INPUT SIGNAL PIN NAME	FREE RUN	SLAVE	FREE RUN	MASTER	MODE
MASTER-SLAVE/NOT FREE RUN	0	1	0	1	
MASTER-NOT SLAVE	X	0	X	1	
	LOGIC LEVEL				

Fig. 3A

TOTOSO" 2E6772760



FIG. 4


34
58
SEND ID (to E1/T1 ST bus, "0" or "1", "coin-toss element)
RECEIVE ID (from E1/T1 ST bus)
56
52
60
62
CLOCK 1
CLOCK 2
RANDOM BIT GENERATOR
COMPARATOR
OUTPUT: GOOD ID (different send and receive)
54
E1/T1 CLOCK BIT TIMING AND FRAME SYNC.
LOS END 1
LOS END 2
STATE CONTROLLER
4 OF 16 FRAME TEST
16 FRAMES IN A ROW TEST
46
68
66
TO E1/T1 FRAMER ST BUS, INSERT/DROP LOGIC AND BUS DIRECTION CONTROL
OUTPUT: PASS/FAIL

Fig. 5


50
74
WAIT
WAITS FOR THE LOS TO BECOME STABLE AND FOR THE UNITS SELF TEST TO END
THE ID BITS ARE THE SAME FROM BOTH ENDS
VERIFY
ARE THE SEND AND RECEIVE ID BITS DIFFERENT? IF YES THE END UNITS HAVE FINISHED THE ID EXCHANGE
70
RESET AND FAULT CONDITIONS RETURN TO THE WAIT STATE
THE LOS SIGNAL IS PRESENT FROM BOTH ENDS SO THIS UNIT DOES NOT TAKE PLACE IN THE ID EXCHANGE
THE LOS SIGNAL IS PRESENT FROM ONLY ONE END SO THIS UNIT TAKES PLACE IN THE ID EXCHANGE
THE SEND ID AND RECEIVE ID HAVE BEEN DIFFERENT FOR 16 CONSECUTIVE FRAMES
THE IDS ARE DIFFERENT FROM BOTH ENDS
66
ID EXCHANGE
THE ID EXCHANGE TAKES PLACE UNTIL THEY ARE DIFFERENT FOR 16 CONSECUTIVE FRAMES
64
THE LOS SIGNAL WAS LOST FROM END 1 AND END 2 OR THE RECEIVED ID WAS THE SAME AS THE ONE BEING SENT FOR AT LEAST 4 OUT OF 16 FRAMES
RUN
THIS IS THE NORMAL OPERATIONAL MODE
72

Fig. 6


TO 38
MASTER-SLAVE/NOT FREE RUN END1
MASTER/NOT SLAVE END1
TO 40
MASTER-SLAVE/NOT FREE RUN END2
TO 42
MASTER/NOT SLAVE END2
TO 44
VCC
D0
D1
D2
D3
D4
D5
D6
D7
O
48A
48B
48D
48C
RX_ID
LOS1
LOS2
ENABLE
S0
S1
S2
E
46

Fig. 7

Fig 7A

Mode Table

LOS1	LOS2	Rx	Address	Master	Slave	Free-run
0	0	0	0	end 2	end 1	
0	0	1	1	end 1	end 2	
0	1	0	2	end 1	end 2	
0	1	1	3	end 1		end 2
1	0	0	4	end 2	end 1	
1	0	1	5	end 2		end 1
1	1	0	6			
1	1	1	7			